

Truck Mats

READ FULL INSTRUCTIONS BEFORE BEGINNING

Instructions may vary for multi-piece sets

1. Verify piece count against the image shown on our website.
2. Compare new and old trunk mat.
3. Check material for accuracy.
4. Install kit according to image layout.

Note: Applying adhesive to hold product in place is generally not necessary. If desired, only apply a light brush or spray adhesive after correct dry fit has been obtained.