

## **Beltline Weatherstrip**

Each door has an inner and outer beltline weatherstrip. The outer beltline moldings mount to the door with clips, rivets, and by pressing on to the flange. The inner usually is attached to the door panel with clips or staples. Before beginning installation, you will need to remove the door panel and old beltline weatherstrip. We recommend starting the installation with the outer beltline first. It is important to properly line up any bends in the weatherstrip with the door frame. Once these weatherstrips are installed it is extremely difficult to remove them for reinstallation without damaging them. Install by pressing clips into slots in the door frame. Once the old beltlines are removed it should be pretty self-explanatory. You will need to install the inner beltline directly to the door panel using the original method prior to re-installing the door panel on the vehicle. *(If installing a new glass run channel, beltlines will need to be installed after the new glass run channel is in place. Some vehicles may require the removal and re-installation of the side view mirror)*